




Waking up your display

To wake the display, press the Power button  on the front control panel.

To return the display to sleep, press the Power button  again.



Writing and erasing on your display


Pick up one of the display's pens and use it to write or draw in digital ink.

Move your fist or palm over the digital ink you want to erase.




Show the connected computer's desktop

After connecting a computer, press **Input**  on the front control panel. Tap the input you want to view on the Input selection menu.



Note: Be sure to enable touch control of your computer by connecting a USB cable from the computer to the appropriate USB-B receptacle on the display.




Use the iQ features

The display includes iQ features that you can use without connecting a computer. To access those features, tap the **Home**  button at the bottom of the screen.

OR

Press **Input**  on the front control panel and tap **OPS**.



You can then use all the iQ features described in the SMART Board display teacher guide (smarttech.com/displayteacherguide).

